



SURF & TURF
INSTANT SHELTERS

5ft MESH SIDEWALL

A STEP-BY-STEP USER GUIDE



MESH SIDEWALL USER GUIDE

PACKAGE CONTENTS



Before beginning, make sure you have all the necessary pieces:

x1 Carrying bag

x1 Hex key

x1 Mesh panel

x1 Vertical bar

x2 Horizontal bars

x2 Elbow joints

x2 Leg clamps

For Canopro Elite and CC:

x1 Inner leg clamp adapter

For Canopro Lite:

x1 Inner leg clamp adapter **x1** Outer leg clamp adapter

MESH SIDEWALL USER GUIDE

1



Slide each of the short horizontal bars into the top and bottom sleeves.

Make sure the button end is toward the side with the velcro straps, and the smooth end toward the sleeve.

2



Slide the elbow joint onto the horizontal bars, making sure they are facing parallel to the buttons on the opposite end.

3



Slide the remaining vertical bar into the sleeve and tighten the elbow joints onto all three bars using the included hex key.

MESH SIDEWALL USER GUIDE

4



Hang the mesh panel by its centre strap on your frame, letting it hang freely in the desired position while you attach the clamps to the legs.

5



For Canopro Elite/CC owners:

Clip the clamp adapter onto the lower leg at the same height as the lower bar.

For Canopro Lite owners:

Clip the **thin** adapter to the **upper leg** at the same height as the upper bar.


Clip the **thick** adapter to the **lower leg** at the same height as the lower bar.

6



Wrap your clamps around the legs and any necessary adapters, aligning the opening to the horizontal poles.

Make sure the pinhole is oriented in the same position as the button on your horizontal pole.



Swing the black knob across the clamp and turn it to tighten onto the leg.

MESH SIDEWALL USER GUIDE

7



Press the button on the horizontal bar, then slide it into the clamp while aligning the locator pin.

Repeat for the lower bar.

8



Loop the remaining top straps to the indicated points on your frame, adjusting each strap until the wall is level.

These straps should be holding most of the weight of the wall.

9



Wrap the velcro straps around the leg to keep the wall steady.

You can also tie the lower elbow joint to a weight for extra stability. (Sold separately)

MESH SIDEWALL USER GUIDE



Now you're ready to display your products!

You can find S-hooks to best suit your product at any hardware store.

Our mesh walls can hold a 30-pound weight on a single hook and still return to their original shape, so it can hold framed artworks with no issue!

Storage tip:

You can make storage quick and easy by simply removing the vertical bar and rolling the mesh panel with the horizontal bars still inside.



For any questions or concerns, please contact us:

905-664-4758

info@gosurfturf.com